


H-0376-0389 PRINTED IN GERMANY FOR REVELL GmbH & Co. KG



INTERESTING FACTS ABOUT BRITAIN'S NEWEST LUXURY LINER

At 40,000 tons the new ORIANA is by far the largest ship ever to be built for the Orient Line and, as with all well designed ships, her speed and size are closely linked.

The Orient Line had been thinking about ORIANA even before ORSOVA, her immediate predecessor, had sailed on her maiden voyage in 1954. It was thought that the new ship would have a service speed faster than ORSOVA's 22½ knots, and it was soon apparent that 27½ knots was the next speed which could maintain a suitable time-table.

Vickers-Armstrongs, who were to build the ship, advised that the smallest ship to achieve this speed economically must have a length of about 800 feet and a shaft horsepower of 80,000.

In designing and building a ship as exciting as ORIANA an enormous amount of research and experiment is necessary. For example, no less than sixteen different types of hull models were run by Vickers-Armstrongs in their experimental tank before the final design was selected. Strangely enough, one of the factors in ORIANA's high speed is the bulbous bow, which is such a prominent feature of the model.

It was also found that by using aluminum for the superstructure instead of the usual steel, so much weight could be saved that it was possible to have an extra deck—thereby increasing the ship's capacity.

Another feature of ORIANA is her unusual funnel. A model was given exhaustive tests in a wind-tunnel before the final design—which ensures that smoke is carried clear of the decks whatever the wind direction—was accepted.

At noon on 3rd November 1959, ORIANA was launched at Barrow-in-Furness by H.R.H. Princess Alexandra.



"ORIANA"—her name and her badge.

According to many scholars the early seventeenth century madrigal, "The Triumph of Oriana" were inspired by the first Queen Elizabeth, and the name therefore links the present age with the earlier era of extensive voyaging and maritime excellence. The badge, with its entwined "O" and "A", symbolizes the link in this form of a monogram.

Assembly Instructions for your

Exciting NEW

Orient Liner Oriana



SOME OF THE SPECIAL FEATURES OF THE ORIANA

A system of transverse propulsion, enabling the ship to move sideways under her own power.

Mobile cranes in place of the conventional derricks.

FOUR swimming pools (one of them is for the crew).

A permanent cinema, complete with balcony.

A television system to pick up local programmes in port and a closed circuit system for use at sea.

Mechanical baggage conveyors which automatically deposit passengers' baggage at the selected deck.

DIMENSIONS OF ORIANA:

Length 854 ft.
Breadth moulded 97 ft.
Maximum draft 31 ft. 6 ins.
Gross tonnage 40,000.

COST OF ORIANA:

Approximately 39 million dollars
ACCOMMODATION:
630 First Class Passengers;
1,500 Tourist Passengers; 900 Crew.

FOR BEST RESULTS, READ THIS FIRST

1. Since this kit is molded of styrene plastic, use only Revell Cement. Do not let cement touch your eyes, furniture or clothing.
2. Apply cement sparingly. Excess cement may

run and damage the details on your model.

3. Carefully trim any excess plastic from the parts before assembling. This will result in parts fitting together perfectly, and also enable moving parts to move freely.

THIS IS VERY IMPORTANT




4. All parts are numbered for easy identification, or the numbers are engraved on the bar next to the part. Carefully remove each part from its bar only when that part is to

be used.

5. Start with No. 42 and cement it to No. 43, etc. Carefully follow these numbered steps for ease in building your model.

With Revell Paint Set Colors, paint all the parts where indicated and allow to dry before assembling. All colors are flagged as shown. **WHITE**



8. Directions for applying decals are on the back of the decal sheet.



6

PAINT ALL DETAILS, AS SHOWN AND LET DRY BEFORE ASSEMBLING


SEE DRAWING A. Cement Parts 16 and 17 together, then cement Part 18 onto Parts 16 and 17. Set aside to dry. SEE DRAWING B. Cement Parts 19 and 20 together then set aside to dry. SEE MAIN DRAWING. Cement Part 23 into place on Assembly 5, as shown. Next, cement Part 22 to Part 15 and Assembly 5, as shown. Now, cement Assembly 8 into place, then cement Assembly A onto 8 and Assembly 5. Finally cement Part 21 into place, as shown. Apply Decals and set aside to dry.



7

PAINT ALL DETAILS, AS SHOWN AND LET DRY BEFORE ASSEMBLING


Cement Assembly 3 to rear of Hull. Slide the front of Assembly 6 under lip on Assembly 2, as shown. Locate Assembly 6 properly, then apply cement. Now cement Assembly 4 to Hull and to Assembly 6, as shown. Next, cement Part 28 up under Part 29, then cement this assembly down onto Assembly 6, being sure Part 29 locates to the Tennis Deck Front, as shown. SNAP. DO NOT CEMENT Part 32 into Deck. Cement Parts 36 and 35 into Deck, as shown. Finally cement (2) Parts 37 and (2) Parts 38 into Deck, then set aside to dry.



8

PAINT ALL DETAILS, AS SHOWN AND LET DRY BEFORE ASSEMBLING

Cement (1) Part 53 into Hull, as shown. Cement (8) Parts 34 into Front of Deck, as shown. Next, cement (7) Parts 31 into place, as shown. SEE DRAWING A. Cement (1) Part 5 onto (1) Part 6. MAKE (6) SETS. Rig Parts 5 and 6 with Household Thread then set aside to dry. SEE MAIN DRAWING. Cement (1) Part 46 into place, as shown. Now, cement Part 55 to side of Hull. Hook tabs on Part 59 between Hull and Lower Deck, then push forward until Part 59 lines up properly. Apply cement to Part 59 and 55. Finally cement (6) Assemblies A into place at front and rear of deck, as shown.



9

PAINT ALL DETAILS, AS SHOWN AND LET DRY BEFORE ASSEMBLING

Turn assembly around, as shown. Cement remaining Parts 46 and 53 into place, as shown. Now hook rear tab on Part 54 to side of Hull and align, then apply cement. Hook tabs on Part 57 between Hull and Lower Deck, then push forward until Part 57 lines up properly. Apply cement to Parts 57 and 54. Next, cement Part 58 to rear of Hull and Side Railings. Cement Part 39 into hole in Bow. SEE DRAWING A. Cement (1) remaining Part 5 onto (1) Part 40. MAKE (2) SETS. Rig Parts 5 and 40, as shown. Next, slide (2) Assemblies A into front locating Rails, as shown. Now, cement Parts 39 and 12 into place. SEE DRAWING BELOW FOR RIGGING, FLAG AND DECAL PLACEMENT.

